



## SOHO UV LACQUERED PANELS CARE AND CLEANING INSTRUCTIONS ---

Leave protective film in place till all other work on the project is completed. The high gloss surface on our UV lacquered doors is very scratch resistant relative to other high gloss products, but care should still be taken not to damage the surface finish.

### **Cleaning**

For best results, use a damp soft cloth with mild soap and water. Do not dry wipe the UV lacquered surface.

Avoid harsh household cleaners and abrasives. The following cleaning agents should not be used under any circumstances:

- Scouring and abrasive agents (abrasive powders, scouring pads, steel wool)
- Polish, washing powder, furniture cleaner, bleach
- Detergents with strong acids and acidic salts
- Steam cleaning equipment

Always check the active ingredients of your cleaners for potentially harmful chemicals. Do not use acetone, ammonia, amylacetate, benzene, butyl acetate, butyl alcohol, caustic soda, cellusolve, chlorinated solvents, chloroform, cresols/phenols, dichloromethane, ethylacetate, glacial acetate acid, halogenated solvents, methyl alcohol, methyl ethyl ketone, thinners, toluene, or xylene.

If chemical or staining liquids are spilled on the UV lacquered surface, wipe it off immediately and wash the surface with soapy water, rinsing several times to eliminate any residue.